



INLINE DRIVE UNIT

Used primarily to transfer post-orientated parts from the feeder bowl to the dead nest, the inline drive unit is set and located so that the lead part arrives exactly where needed. In correlation with the dead nest, final part height and location is set to required parameters.



- COIL
- INLINE BODY (COUNTER WEIGHT)
- RISERS
- JACKING SCREWS
- MOUNTING PLATE WITH MOUNTING HOLES



SPRING BANKS